

BRACKET KIT PART NUMBER LIST

S T A N D A R D

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
ACTREG		
A20	CALL	CALL
A40	CALL	CALL
A80	CALL	CALL
A130	CALL	CALL
A200	CALL	CALL
A300	CALL	CALL
A500	CALL	CALL
A850	CALL	CALL
A1200	CALL	CALL
A1750	CALL	CALL
AIRTECH		
PA050	BKT-RP001	BKT-RS001
PA063	BKT-RP001	BKT-RS001
PA075	BKT-RP002	BKT-RS002
PA085	BKT-RP002	BKT-RS002
PA100	BKT-RP002	BKT-RS002
PA115	BKT-RP003	BKT-RS003
PA125	BKT-RP003	BKT-RS003
PA160	BKT-RP003	BKT-RS003
PA200	BKT-RP012	BKT-RS012
PA270	BKT-RP185	BKT-RS185
AIRTORQUE		
AT0	BKT-RP001	BKT-RS001
AT0.5	BKT-RP001	BKT-RS001
AT1	BKT-RP001	BKT-RS001
AT2	BKT-RP002	BKT-RS002
AT2.5	BKT-RP002	BKT-RS002
AT3	BKT-RP002	BKT-RS002
AT3.5	BKT-RP003	BKT-RS003
AT4	BKT-RP003	BKT-RS003
AT5	BKT-RP003	BKT-RS003
AT6	BKT-RP003	BKT-RS003
AT7	BKT-RP003	BKT-RS003
AUTOMATOR-II		
PA032	BKT-RP001	BKT-RS001
PA050*	BKT-RP001	BKT-RS001
PA063*	BKT-RP001	BKT-RS001
PA075*	BKT-RP002	BKT-RS002
PA085*	BKT-RP002	BKT-RS002
PA100*	BKT-RP002	BKT-RS002
PA125	BKT-RP003	BKT-RS003
PA160	BKT-RP161	BKT-RS161
PA200	BKT-RP162	BKT-RS162
AUTOMAX		
SNA50	BKT-RP187	BKT-RS187
SNA63	BKT-RP187	BKT-RS187
SNA85	BKT-RP002	BKT-RS002
SNA100	BKT-RP002	BKT-RS002
SNA115	BKT-RP164	BKT-RS164
SNA125	BKT-RP164	BKT-RS164
SNA150	BKT-RP030	BKT-RS030
SNA175	BKT-RP030	BKT-RS030
SNA200	BKT-RP030	BKT-RS030
A32	BKT-RP137	BKT-RS137
N250	BKT-RP138	BKT-RS138
N300	BKT-RP139	BKT-RS139

N A M U R

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
ACTREG		
A20	BKT-NP151	BKT-NS151
A40	BKT-NP151	BKT-NS151
A80	BKT-NP151	BKT-NS151
A130	BKT-NP151	BKT-NS151
A200	BKT-NP151	BKT-NS151
A300	BKT-NP151	BKT-NS151
A500	BKT-NP151	BKT-NS151
A850	BKT-NP151	BKT-NS151
A1200	CALL	CALL
A1750	CALL	CALL
AIRTECH		
PA050*	BKT-NP120	BKT-NS120
PA063*	BKT-NP120	BKT-NS120
PA075*	BKT-NP120	BKT-NS120
PA085*	BKT-NP120	BKT-NS120
PA100*	BKT-NP120	BKT-NS120
PA115	BKT-NP130	BKT-NS130
PA125	BKT-NP130	BKT-NS130
PA160	BKT-NP130	BKT-NS130
PA200	BKT-NP130	BKT-NS130
PA270	BKT-NP130	BKT-NS130
AIRTORQUE		
AT0*	BKT-NP120	BKT-NS120
AT0.5	BKT-NP120	BKT-NS120
AT1*	BKT-NP120	BKT-NS120
AT2*	BKT-NP120	BKT-NS120
AT2.5*	BKT-NP120	BKT-NS120
AT3	BKT-NP120	BKT-NS120
AT3.5	BKT-NP130	BKT-NS130
AT4	BKT-NP130	BKT-NS130
AT5	BKT-NP130	BKT-NS130
AT6	BKT-NP130	BKT-NS130
AT7	BKT-NP130	BKT-NS130
AUTOMATOR-II		
PA032	BKT-NP156	BKT-NS156
PA050*	BKT-NP120	BKT-NS120
PA063*	BKT-NP120	BKT-NS120
PA075*	BKT-NP120	BKT-NS120
PA085*	BKT-NP120	BKT-NS120
PA100*	BKT-NP130	BKT-NS120
PA125	BKT-NP130	BKT-NS130
PA160	BKT-NP161	BKT-NS161
PA200	BKT-NP161	BKT-NS161
AUTOMAX		
SNA50*	BKT-NP120	BKT-NS120
SNA63*	BKT-NP120	BKT-NS120
SNA85*	BKT-NP120	BKT-NS120
SNA100*	BKT-NP120	BKT-NS120
SNA115	BKT-NP130	BKT-NS130
SNA125	BKT-NP130	BKT-NS130
SNA150	BKT-NP130	BKT-NS130
SNA175	BKT-NP130	BKT-NS130
SNA200	BKT-NP130	BKT-NS130
A32	N/A	N/A
N250	N/A	N/A
N300	N/A	N/A

BRACKET KIT PART NUMBER LIST

STANDARD

ACTUATOR	PLATED STEEL	STAINLESS STEEL
BETTIS		
CB-315	BKT-RP046	<i>BKT-RS046</i>
CB-415	BKT-RP046	<i>BKT-RS046</i>
CB-420	BKT-RP047	<i>BKT-RS047</i>
CB-520	BKT-RP047	<i>BKT-RS047</i>
CB-525	BKT-RP048	<i>BKT-RS048</i>
CB-725	BKT-RP048	<i>BKT-RS048</i>
HD-521	BKT-RP068	<i>BKT-RS068</i>
HD-721	BKT-RP068	<i>BKT-RS068</i>
HD-722	BKT-RP068	<i>BKT-RS068</i>
HD-731	BKT-RP069	<i>BKT-RS069</i>
HD-732	BKT-RP069	<i>BKT-RS069</i>
HD-251	BKT-RP068	<i>BKT-RS068</i>
HD-352	BKT-RP069	<i>BKT-RS069</i>
RPCSeries(All)	BKT-RP149	<i>BKT-RS149</i>
GSeries(All)	BKT-RP149	<i>BKT-RS149</i>
T3	BKT-RP146	<i>BKT-RS146</i>
T4	BKT-RP147	<i>BKT-RP147</i>
T5	BKT-RP148	<i>BKT-RP148</i>
BI-TORQ		
BI-32	CALL	<i>CALL</i>
BI-52	CALL	<i>CALL</i>
BI-63	CALL	<i>CALL</i>
BI-75	CALL	<i>CALL</i>
BI-85	CALL	<i>CALL</i>
BI-100	CALL	<i>CALL</i>
BI-125	CALL	<i>CALL</i>
BI-160	CALL	<i>CALL</i>
BI-200	CALL	<i>CALL</i>
BRAY		
63	BKT-RP128	<i>BKT-RS128</i>
83	BKT-RP129	<i>BKT-RS129</i>
92	BKT-RP129	<i>BKT-RS129</i>
118	BKT-RP130	<i>BKT-RS130</i>
127	BKT-RP130	<i>BKT-RS130</i>
160	CALL	<i>CALL</i>
210	CALL	<i>CALL</i>
255A	CALL	<i>CALL</i>
255B	CALL	<i>CALL</i>
COMPACTORQUE		
CTS-10	N/A	<i>N/A</i>
CTS-20	N/A	<i>N/A</i>
CTS-30	BKT-RP001	<i>BKT-RS001</i>
CTS-40	BKT-RP002	<i>BKT-RS002</i>
CTS-50	BKT-RP002	<i>BKT-RS002</i>
CTS-60	BKT-RP002	<i>BKT-RS002</i>
CTS-65	BKT-RP003	<i>BKT-RS003</i>
CTS-70	BKT-RP003	<i>BKT-RS003</i>
CTS-80	BKT-RP003	<i>BKT-RS003</i>
CTS-90	BKT-RP003	<i>BKT-RS003</i>
CONTROMATICS		
PA/PAS150	BKT-RP013	<i>BKT-RS013</i>
PA/PAS400	BKT-RP013	<i>BKT-RS013</i>
PA/PAS1000	BKT-RP013	<i>BKT-RS013</i>
PA/PAS1500	BKT-RP013	<i>BKT-RS013</i>
PA/PAS2250	N/A	<i>N/A</i>
PA/PAS3000	BKT-RP014	<i>BKT-RS014</i>

NAMUR

ACTUATOR	PLATED STEEL	STAINLESS STEEL
BETTIS		
CB-315	N/A	<i>N/A</i>
CB-415	N/A	<i>N/A</i>
CB-420	N/A	<i>N/A</i>
CB-520	N/A	<i>N/A</i>
CB-525	N/A	<i>N/A</i>
CB-725	N/A	<i>N/A</i>
HD-521	N/A	<i>N/A</i>
HD-721	N/A	<i>N/A</i>
HD-722	N/A	<i>N/A</i>
HD-731	N/A	<i>N/A</i>
HD-732	N/A	<i>N/A</i>
HD-251	N/A	<i>N/A</i>
HD-352	N/A	<i>N/A</i>
RPCSeries(All)*	BKT-NP120	<i>BKT-NS120</i>
GSeries(All)*	BKT-NP120	<i>BKT-NS120</i>
T3	N/A	<i>N/A</i>
T4	N/A	<i>N/A</i>
T5	N/A	<i>N/A</i>
BI-TORQ		
BI-32	CALL	<i>CALL</i>
BI-52	BKT-NP151	<i>BKT-NS151</i>
BI-63	BKT-NP151	<i>BKT-NS151</i>
BI-75	BKT-NP151	<i>BKT-NS151</i>
BI-85	BKT-NP151	<i>BKT-NS151</i>
BI-100	BKT-NP151	<i>BKT-NS151</i>
BI-125	BKT-NP151	<i>BKT-NS151</i>
BI-160	BKT-NP151	<i>BKT-NS151</i>
BI-200	BKT-NP151	<i>BKT-NS151</i>
BRAY		
63	BKT-NP153	<i>BKT-NS153</i>
83	BKT-NP153	<i>BKT-NS153</i>
92	BKT-NP153	<i>BKT-NS153</i>
118	BKT-NP153	<i>BKT-NS153</i>
127	BKT-NP153	<i>BKT-NS153</i>
160	BKT-NP154	<i>BKT-NS154</i>
210	BKT-NP154	<i>BKT-NS154</i>
255A	BKT-NP154	<i>BKT-NS154</i>
255B	BKT-NP154	<i>BKT-NS154</i>
COMPACTORQUE		
CTS-10	BKT-NP156	<i>BKT-NS156</i>
CTS-20	BKT-NP156	<i>BKT-NS156</i>
CTS-30*	BKT-NP120	<i>BKT-NS120</i>
CTS-40*	BKT-NP120	<i>BKT-NS120</i>
CTS-50*	BKT-NP120	<i>BKT-NS120</i>
CTS-60*	BKT-NP120	<i>BKT-NS120</i>
CTS-65	BKT-NP130	<i>BKT-NS130</i>
CTS-70	BKT-NP130	<i>BKT-NS130</i>
CTS-80	BKT-NP130	<i>BKT-NS130</i>
CTS-90	BKT-NP130	<i>BKT-NS130</i>
CONTROMATICS		
PA/PAS150	BKT-NP120	<i>BKT-NS120</i>
PA/PAS400	BKT-NP120	<i>BKT-NS120</i>
PA/PAS1000	BKT-NP120	<i>BKT-NS120</i>
PA/PAS1500	BKT-NP120	<i>BKT-NS120</i>
PA/PAS2250	BKT-NP120	<i>BKT-NS120</i>
PA/PAS3000	BKT-NP120	<i>BKT-NS120</i>

BRACKET KIT PART NUMBER LIST

STANDARD

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
CONTRO.,cont.		
PA/PAS7000	BKT-RP015	<i>BKT-RS015</i>
200B	BKT-RP110	<i>BKT-RS110</i>
275B	BKT-RP111	<i>BKT-RS111</i>
375B	BKT-RP112	<i>BKT-RS112</i>
500B	BKT-RP113	<i>BKT-RS113</i>
EL-O-MATIC		
EDN/ESA12	CALL	CALL
EDN/ESA25	BKT-RP032	<i>BKT-RS032</i>
EDN/ESA40	BKT-RP002	<i>BKT-RS002</i>
EDN/ESA65	BKT-RP002	<i>BKT-RS002</i>
EDN/ESA100	BKT-RP002	<i>BKT-RS002</i>
EDN/ESA200	BKT-RP168	<i>BKT-RS168</i>
EDN/ESA350	BKT-RP168	<i>BKT-RS168</i>
EDN/ESA600	BKT-RP030	<i>BKT-RS030</i>
EDN/ESA950	BKT-RP030	<i>BKT-RS030</i>
PDN/PSA2500	BKT-RP030	<i>BKT-RS030</i>
PDN/PSA4000	BKT-RP030	<i>BKT-RS030</i>
FISHER		
1032-45	BKT-RP053	<i>BKT-RS053</i>
1032-70	BKT-RP054	<i>BKT-RS054</i>
1032-130	BKT-RP054	<i>BKT-RS054</i>
1032-185	BKT-RP054	<i>BKT-RS054</i>
1032-280	BKT-RP054	<i>BKT-RS054</i>
1032-425	BKT-RP055	<i>BKT-RS055</i>
1032-680	BKT-RP055	<i>BKT-RS055</i>
1032-1125	BKT-RP056	<i>BKT-RS056</i>
1032-1370	BKT-RP056	<i>BKT-RS056</i>
1032-2585	BKT-RP057	<i>BKT-RS057</i>
1032-4580	BKT-RP057	<i>BKT-RS057</i>
1052-20	BKT-RP099	<i>BKT-RS099</i>
FLO-TORK		
FP63	BKT-RP001	<i>BKT-RS001</i>
FP75	BKT-RP002	<i>BKT-RS002</i>
FP85	BKT-RP002	<i>BKT-RS002</i>
FP100	BKT-RP002	<i>BKT-RS002</i>
FP125	BKT-RP003	<i>BKT-RS003</i>
FP160	BKT-RP003	<i>BKT-RS003</i>
FP200	BKT-RP012	<i>BKT-RS012</i>
FP250	BKT-RP189	<i>BKT-RS189</i>
HYTORK		
XL45	BKT-RP053	<i>BKT-RS053</i>
XL70	BKT-RP054	<i>BKT-RS054</i>
XL130	BKT-RP054	<i>BKT-RS054</i>
XL185	BKT-RP054	<i>BKT-RS054</i>
XL280	BKT-RP054	<i>BKT-RS054</i>
XL425	BKT-RP055	<i>BKT-RS055</i>
XL680	BKT-RP055	<i>BKT-RS055</i>
XL1125	BKT-RP056	<i>BKT-RS056</i>
XL1370	BKT-RP056	<i>BKT-RS056</i>
XL2585	BKT-RP057	<i>BKT-RS057</i>
XL4580	BKT-RP057	<i>BKT-RS057</i>
JAMESBURY(NELES)		
BCU6	N/A	N/A
BCU9/BJU8	N/A	N/A
BCU11/BJU10	N/A	N/A
BCU13/BJU12	N/A	N/A

NAMUR

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
CONTRO.,cont		
PA/PAS7000	BKT-NP151	BKT-NS151
200B	N/A	N/A
275B	N/A	N/A
375B	N/A	N/A
500B	N/A	N/A
EL-O-MATIC		
EDN/ESA12	BKT-NP157	<i>BKT-NS157</i>
EDN/ESA25	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA40	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA65	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA100	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA200	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA350	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA600	BKT-NP130	<i>BKT-NS130</i>
EDN/ESA950	BKT-NP130	<i>BKT-NS130</i>
PDN/PSA2500	BKT-NP130	<i>BKT-NS130</i>
PDN/PSA4000	BKT-NP130	<i>BKT-NS130</i>
FISHER		
1032-45*	BKT-NP120	<i>BKT-NS120</i>
1032-70*	BKT-NP120	<i>BKT-NS120</i>
1032-130*	BKT-NP120	<i>BKT-NS120</i>
1032-185*	BKT-NP120	<i>BKT-NS120</i>
1032-280	BKT-NP120	<i>BKT-NS120</i>
1032-425	BKT-NP160	<i>BKT-NS160</i>
1032-680	BKT-NP160	<i>BKT-NS160</i>
1032-1125	BKT-NP130	<i>BKT-NS130</i>
1032-1370	BKT-NP130	<i>BKT-NS130</i>
1032-2585	BKT-NP130	<i>BKT-NS130</i>
1032-4580	BKT-NP130	<i>BKT-NS130</i>
1052-20	N/A	N/A
FLO-TORK		
FP63	BKT-NP120	<i>BKT-NS120</i>
FP75	BKT-NP120	<i>BKT-NS120</i>
FP85	BKT-NP120	<i>BKT-NS120</i>
FP100	BKT-NP120	<i>BKT-NS120</i>
FP125	BKT-NP130	<i>BKT-NS130</i>
FP160	BKT-NP130	<i>BKT-NS130</i>
FP200	BKT-NP130	<i>BKT-NS130</i>
FP250	BKT-NP130	<i>BKT-NS130</i>
HYTORK		
XL45*	BKT-NP120	<i>BKT-NS120</i>
XL70*	BKT-NP120	<i>BKT-NS120</i>
XL130*	BKT-NP120	<i>BKT-NS120</i>
XL185*	BKT-NP120	<i>BKT-NS120</i>
XL280	BKT-NP120	<i>BKT-NS120</i>
XL425	BKT-NP160	<i>BKT-NS160</i>
XL680	BKT-NP160	<i>BKT-NS160</i>
XL1125	BKT-NP130	<i>BKT-NS130</i>
XL1370	BKT-NP130	<i>BKT-NS130</i>
XL2585	BKT-NP130	<i>BKT-NS130</i>
XL4580	BKT-NP130	<i>BKT-NS130</i>
JAMESBURY(NELES)		
BCU6	BKT-NP120	<i>BKT-NS120</i>
BCU9/BJU8	BKT-NP158	<i>BKT-NS158</i>
BCU11/BJU10	BKT-NP158	<i>BKT-NS158</i>
BCU13/BJU12	BKT-NP130	<i>BKT-NS158</i>

BRACKET KIT PART NUMBER LIST

S T A N D A R D

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
BCU17/BJU16	N/A	N/A
BCU20/BJU20	N/A	N/A
BCU25/BJU25	N/A	N/A
BCU32/BJU32	N/A	N/A
BCU40	N/A	N/A
BCU50	N/A	N/A
QP1ABCD	BKT-RP073	<i>BKT-RS073</i>
QP2ABCD	BKT-RP073	<i>BKT-RS073</i>
QP3ABCD	BKT-RP107	<i>BKT-RS107</i>
QP4ABCD	BKT-RP108	<i>BKT-RS108</i>
QP5ABCD	BKT-RP108	<i>BKT-RS108</i>
QPF(All)	BKT-RP074	<i>BKT-RS074</i>
SP25	BKT-RP044	<i>BKT-RS044</i>
SP50	BKT-RP044	<i>BKT-RS044</i>
SP100	BKT-RP045	<i>BKT-RS045</i>
SP200	BKT-RP045	<i>BKT-RS045</i>
SP6SR60	BKT-RP044	<i>BKT-RS044</i>
SP9SR80	BKT-RP044	<i>BKT-RS044</i>
SP8SR40	BKT-RP044	<i>BKT-RS044</i>
SP13SR60	BKT-RP044	<i>BKT-RS044</i>
SP18SR80	BKT-RP044	<i>BKT-RS044</i>
SP18SR40	BKT-RP045	<i>BKT-RS045</i>
SP26SR60	BKT-RP045	<i>BKT-RS045</i>
SP36SR80	BKT-RP045	<i>BKT-RS045</i>
SP36SR40	BKT-RP045	<i>BKT-RS045</i>
SP52SR60	BKT-RP045	<i>BKT-RS045</i>
SP72SR80	BKT-RP045	<i>BKT-RS045</i>
ST13	BKT-RP064	<i>BKT-RS064</i>
ST20	BKT-RP064	<i>BKT-RS064</i>
ST50	BKT-RP064	<i>BKT-RS064</i>
ST60	BKT-RP071	<i>BKT-RS071</i>
ST90	BKT-RP071	<i>BKT-RS071</i>
ST115	BKT-RP071	<i>BKT-RS071</i>
ST175	BKT-RP071	<i>BKT-RS071</i>
ST160	BKT-RP126	<i>BKT-RS126</i>
ST240	BKT-RP126	<i>BKT-RS126</i>
ST290	BKT-RP126	<i>BKT-RS126</i>
ST440	BKT-RP126	<i>BKT-RS126</i>
ST200	BKT-RP157	<i>BKT-RS157</i>
ST400	BKT-RP157	<i>BKT-RS157</i>
ST600	BKT-RP179	<i>BKT-RS179</i>
ST1200	BKT-RP179	<i>BKT-RS179</i>
ST1800	BKT-RP179	<i>BKT-RS179</i>
VP02	N/A	N/A
VP04	N/A	N/A
VP08	N/A	N/A
VP10	N/A	N/A
VP12	N/A	N/A
VP14	N/A	N/A
VP22	N/A	N/A
V60	BKT-RP044	<i>BKT-RS044</i>
V150	BKT-RP045	<i>BKT-RS045</i>
V400	BKT-RP108	<i>BKT-RS108</i>
VP-VL01	CALL	CALL
VP-VL050	BKT-RP001	<i>BKT-RS001</i>
VP-VL100	BKT-RP001	<i>BKT-RS001</i>
VP-VL200	BKT-RP002	<i>BKT-RS002</i>

N A M U R

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
BC17/BJ16	BKT-NP130	<i>BKT-NS130</i>
BC20/BJ20	BKT-NP130	<i>BKT-NS130</i>
BC25/BJ25	CALL	N/A
BC32/BJ32	CALL	N/A
BC40	CALL	N/A
BC50	CALL	N/A
QP1ABCD	N/A	N/A
QP2ABCD	N/A	N/A
QP3ABCD	N/A	N/A
QP4ABCD	N/A	N/A
QP5ABCD	N/A	N/A
QPF(All)	N/A	N/A
SP25	N/A	N/A
SP50	N/A	N/A
SP100	N/A	N/A
SP200	N/A	N/A
SP6SR60	N/A	N/A
SP9SR80	N/A	N/A
SP8SR40	N/A	N/A
SP13SR60	N/A	N/A
SP18SR80	N/A	N/A
SP18SR40	N/A	N/A
SP26SR60	N/A	N/A
SP36SR80	N/A	N/A
SP36SR40	N/A	N/A
SP52SR60	N/A	N/A
SP72SR80	N/A	N/A
ST13	N/A	N/A
ST20	N/A	N/A
ST50	N/A	N/A
ST60	N/A	N/A
ST90	N/A	N/A
ST115	N/A	N/A
ST175	N/A	N/A
ST160	N/A	N/A
ST240	N/A	N/A
ST290	N/A	N/A
ST440	N/A	N/A
ST200	N/A	N/A
ST400	N/A	N/A
ST600	N/A	N/A
ST1200	N/A	N/A
ST1800	N/A	N/A
VP02	BKT-NP120	<i>BKT-NS120</i>
VP04	BKT-NP120	<i>BKT-NS120</i>
VP08	BKT-NP151	<i>BKT-NS151</i>
VP10	BKT-NP151	<i>BKT-NS151</i>
VP12	BKT-NP161	<i>BKT-NS161</i>
VP14	BKT-NP161	<i>BKT-NS161</i>
VP22	BKT-NP161	<i>BKT-NS161</i>
V60	N/A	N/A
V150	N/A	N/A
V400	N/A	N/A
VP-VL01	BKT-NP156	<i>BKT-NS156</i>
VP-VL050	BKT-NP120	<i>BKT-NS120</i>
VP-VL100	BKT-NP120	<i>BKT-NS120</i>
VP-VL200	BKT-NP120	<i>BKT-NS120</i>

BRACKET KIT PART NUMBER LIST

S T A N D A R D

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
VP-VL250	BKT-RP002	<i>BKT-RS002</i>
VP-VL300	BKT-RP002	<i>BKT-RS002</i>
VP-VL350	CALL	<i>CALL</i>
VP-VL400	CALL	<i>CALL</i>
VP-VL450	CALL	<i>CALL</i>
VP-VL500	CALL	<i>CALL</i>
VP-VL550	CALL	<i>CALL</i>
VP-VL600	CALL	<i>CALL</i>
VP-VL700-	CALL	<i>CALL</i>
K-TORK		
K-1	CALL	<i>CALL</i>
K-2	CALL	<i>CALL</i>
K-3	CALL	<i>CALL</i>
K-4	CALL	<i>CALL</i>
K-5	CALL	<i>CALL</i>
K-6	CALL	<i>CALL</i>
KINETROL		
00	N/A	<i>N/A</i>
01	BKT-RP114	<i>BKT-RS114</i>
02	BKT-RP115	<i>BKT-RS115</i>
03	BKT-RP116	<i>BKT-RS116</i>
05	BKT-RP117	<i>BKT-RS117</i>
07	BKT-RP118	<i>BKT-RS118</i>
08	BKT-RP119	<i>BKT-RS119</i>
09	BKT-RP120	<i>BKT-RS120</i>
10	BKT-RP121	<i>BKT-RS121</i>
12	BKT-RP122	<i>BKT-RS122</i>
14	BKT-RP123	<i>BKT-RS123</i>
16	BKT-RP124	<i>BKT-RS124</i>
18	BKT-RP125	<i>BKT-RS125</i>
MATRYX		
MX60	BKT-RP004	<i>BKT-RS004</i>
MX200	BKT-RP005	<i>BKT-RS005</i>
MX450	BKT-RP006	<i>BKT-RS006</i>
MX750	BKT-RP006	<i>BKT-RS006</i>
MX1250	BKT-RP006	<i>BKT-RS006</i>
MX3000	BKT-RP007	<i>BKT-RS007</i>
EDN/ESA12	CALL	<i>CALL</i>
EDN/ESA25	BKT-RP032	<i>BKT-RS032</i>
EDN/ESA40	BKT-RP002	<i>BKT-RS002</i>
EDN/ESA65	BKT-RP002	<i>BKT-RS002</i>
EDN/ESA100	BKT-RP002	<i>BKT-RS002</i>
EDN/ESA200	BKT-RP168	<i>BKT-RS168</i>
EDN/ESA350	BKT-RP168	<i>BKT-RS168</i>
EDN/ESA600	BKT-RP030	<i>BKT-RS030</i>
EDN/ESA950	BKT-RP030	<i>BKT-RS030</i>
PDN/PSA2500	BKT-RP030	<i>BKT-RS030</i>
PDN/PSA4000	BKT-RP030	<i>BKT-RS030</i>
MCF		
MDA/SR2	BKT-RP088	<i>BKT-RS088</i>
MDA/SR4	BKT-RP088	<i>BKT-RS088</i>
MDA/SR8	BKT-RP088	<i>BKT-RS088</i>
MDA/SR12	BKT-RP088	<i>BKT-RS088</i>
MDA/SR20	BKT-RP089	<i>BKT-RS089</i>
MDA/SR35	BKT-RP090	<i>BKT-RS090</i>
MDA/SR55	BKT-RP091	<i>BKT-RS091</i>
MDA/SR70	BKT-RP091	<i>BKT-RS091</i>

N A M U R

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
VP-VL250	BKT-NP120	<i>BKT-NS120</i>
VP-VL300	BKT-NP120	<i>BKT-NS120</i>
VP-VL350	BKT-NP164	<i>BKT-NS164</i>
VP-VL400	BKT-NP164	<i>BKT-NS164</i>
VP-VL450	BKT-NP164	<i>BKT-NS164</i>
VP-VL500	BKT-NP164	<i>BKT-NS164</i>
VP-VL550	BKT-NP131	<i>BKT-NS131</i>
VP-VL600	BKT-NP131	<i>BKT-NS131</i>
VP-VL700	BKT-NP131	<i>BKT-NS131</i>
K-TORK		
K-1*	BKT-NP120	<i>BKT-NS120</i>
K-2*	BKT-NP120	<i>BKT-NS120</i>
K-3	BKT-NP120	<i>BKT-NS120</i>
K-4	BKT-NP120	<i>BKT-NS120</i>
K-5	BKT-NP120	<i>BKT-NS120</i>
K-6	BKT-NP120	<i>BKT-NS120</i>
KINETROL		
00	N/A	<i>N/A</i>
01	N/A	<i>N/A</i>
02	N/A	<i>N/A</i>
03	N/A	<i>N/A</i>
05	N/A	<i>N/A</i>
07	N/A	<i>N/A</i>
08	N/A	<i>N/A</i>
09	N/A	<i>N/A</i>
10	N/A	<i>N/A</i>
12	N/A	<i>N/A</i>
14	N/A	<i>N/A</i>
16	N/A	<i>N/A</i>
18	N/A	<i>N/A</i>
MATRYX		
MX60	N/A	<i>N/A</i>
MX200	N/A	<i>N/A</i>
MX450	N/A	<i>N/A</i>
MX750	N/A	<i>N/A</i>
MX1250	N/A	<i>N/A</i>
MX3000	N/A	<i>N/A</i>
EDN/ESA12	BKT-NP157	<i>BKT-NS157</i>
EDN/ESA25*	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA40*	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA65*	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA100*	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA200*	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA350	BKT-NP120	<i>BKT-NS120</i>
EDN/ESA600	BKT-NP130	<i>BKT-NS130</i>
EDN/ESA950	BKT-NP130	<i>BKT-NS130</i>
PDN/PSA2500	BKT-NP130	<i>BKT-NS130</i>
PDN/PSA4000	BKT-NP130	<i>BKT-NS130</i>
MCF		
MDA/SR2*	BKT-NP120	<i>BKT-NS120</i>
MDA/SR4*	BKT-NP120	<i>BKT-NS120</i>
MDA/SR8*	BKT-NP120	<i>BKT-NS120</i>
MDA/SR12	BKT-NP120	<i>BKT-NS120</i>
MDA/SR20	BKT-NP120	<i>BKT-NS120</i>
MDA/SR35	BKT-NP158	<i>BKT-NS158</i>
MDA/SR55	BKT-NP130	<i>BKT-NS130</i>
MDA/SR70	BKT-NP130	<i>BKT-NS130</i>

BRACKET KIT PART NUMBER LIST

STANDARD

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
MDA/SR100	BKT-RP091	<i>BKT-RS091</i>
MDA/SR150	BKT-RP091	<i>BKT-RS091</i>
MDA/SR250	CALL	CALL
MDA/SR400	CALL	CALL
MORIN		
03DA/SR	BKT-RP150	<i>BKT-RS150</i>
06DA/SR	BKT-RP059	<i>BKT-RS059</i>
12DA/SR	BKT-RP059	<i>BKT-RS059</i>
23DA/SR	BKT-RP060	<i>BKT-RS060</i>
36DA/SR	BKT-RP060	<i>BKT-RS060</i>
46DA/SR	BKT-RP060	<i>BKT-RS060</i>
72DA/SR	BKT-RP060	<i>BKT-RS060</i>
100DA/SR	BKT-RP060	<i>BKT-RS060</i>
144DA/SR	BKT-RP061	<i>BKT-RS061</i>
135DA/SR	BKT-RP172	<i>BKT-RS172</i>
210DA/SR	BKT-RP172	<i>BKT-RS172</i>
270DA/SR	BKT-RP172	<i>BKT-RS172</i>
370DA/SR	BKT-RP172	<i>BKT-RS172</i>
420DA/SR	BKT-RP172	<i>BKT-RS172</i>
575DA/SR	BKT-RP172	<i>BKT-RS172</i>
740DA/SR	BKT-RP172	<i>BKT-RS172</i>
1150DA/SR	BKT-RP172	<i>BKT-RS172</i>
NIBCO		
SIZE2	BKT-RP088	<i>BKT-RS088</i>
SIZE4	BKT-RP088	<i>BKT-RS088</i>
SIZE8	BKT-RP088	<i>BKT-RS088</i>
SIZE12	BKT-RP088	<i>BKT-RS088</i>
SIZE20	BKT-RP089	<i>BKT-RS089</i>
SIZE35	BKT-RP090	<i>BKT-RS090</i>
SIZE55	BKT-RP091	<i>BKT-RS091</i>
SIZE70	BKT-RP091	<i>BKT-RS091</i>
SIZE100	BKT-RP091	<i>BKT-RS091</i>
SIZE150	BKT-RP091	<i>BKT-RS091</i>
SIZE250	CALL	CALL
SIZE400	CALL	CALL
QTRCO		
R04	CALL	CALL
R05	CALL	CALL
R07	CALL	CALL
R10	CALL	CALL
R12	CALL	CALL
R14	CALL	CALL
RADIUS		
AD/AS005A	BKT-RP001	<i>BKT-RS001</i>
AD/AS008A	BKT-RP001	<i>BKT-RS001</i>
AD/AS012A	BKT-RP008	<i>BKT-RS008</i>
AD/AS020A	CALL	CALL
AD/AS030A	CALL	CALL
AD/AS040A	CALL	CALL
AD/AS060A	CALL	CALL
AD/AS100A	CALL	CALL
AD/AS200A	CALL	CALL
AD/AS250A	CALL	CALL
AD/AS370A	CALL	CALL
AD/AS500A	CALL	CALL
AD/AS750A	CALL	CALL

NAMUR

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
MDA/SR100	BKT-NP130	<i>BKT-NS130</i>
MDA/SR150	BKT-NP130	<i>BKT-NS130</i>
MDA/SR250	BKT-NP159	<i>BKT-NS159</i>
MDA/SR400	BKT-NP159	<i>BKT-NS159</i>
MORIN		
03DA/SR	N/A	N/A
06DA/SR	N/A	N/A
12DA/SR	N/A	N/A
23DA/SR	N/A	N/A
36DA/SR	N/A	N/A
46DA/SR	N/A	N/A
72DA/SR	N/A	N/A
100DA/SR	N/A	N/A
144DA/SR	N/A	N/A
135DA/SR	N/A	N/A
210DA/SR	N/A	N/A
270DA/SR	N/A	N/A
370DA/SR	N/A	N/A
420DA/SR	N/A	N/A
575DA/SR	N/A	N/A
740DA/SR	N/A	N/A
1150DA/SR	N/A	N/A
NIBCO		
SIZE2*	BKT-NP120	<i>BKT-NS120</i>
SIZE4*	BKT-NP120	<i>BKT-NS120</i>
SIZE8*	BKT-NP120	<i>BKT-NS120</i>
SIZE12	BKT-NP120	<i>BKT-NS120</i>
SIZE20	BKT-NP120	<i>BKT-NS120</i>
SIZE35	BKT-NP158	<i>BKT-NS158</i>
SIZE55	BKT-NP130	<i>BKT-NS130</i>
SIZE70	BKT-NP130	<i>BKT-NS130</i>
SIZE100	BKT-NP130	<i>BKT-NS130</i>
SIZE150	BKT-NP130	<i>BKT-NS130</i>
SIZE250	BKT-NP159	<i>BKT-NS159</i>
SIZE400	BKT-NP159	<i>BKT-NS159</i>
QTRCO		
R04*	BKT-NP120	<i>BKT-NS120</i>
R05*	BKT-NP120	<i>BKT-NS120</i>
R07*	BKT-NP120	<i>BKT-NS120</i>
R10*	BKT-NP120	<i>BKT-NS120</i>
R12	BKT-NP120	<i>BKT-NS120</i>
R14	BKT-NP120	<i>BKT-NS120</i>
RADIUS		
AD/AS005A*	BKT-NP120	<i>BKT-NS120</i>
AD/AS008A*	BKT-NP120	<i>BKT-NS120</i>
AD/AS012A*	BKT-NP120	<i>BKT-NS120</i>
AD/AS020A*	BKT-NP120	<i>BKT-NS120</i>
AD/AS030A*	BKT-NP120	<i>BKT-NS120</i>
AD/AS040A	BKT-NP151	<i>BKT-NS151</i>
AD/AS060A	BKT-NP151	<i>BKT-NS151</i>
AD/AS100A	BKT-NP151	<i>BKT-NS151</i>
AD/AS200A	BKT-NP151	<i>BKT-NS151</i>
AD/AS250A	BKT-NP151	<i>BKT-NS151</i>
AD/AS370A	BKT-NP151	<i>BKT-NS151</i>
AD/AS500A	BKT-NP130	<i>BKT-NS130</i>
AD/AS750A	BKT-NP130	<i>BKT-NS130</i>

BRACKET KIT PART NUMBER LIST

STANDARD

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
REMOTECONTROL		
RC-1210	BKT-RP035	<i>BKT-RS035</i>
RC-1220	BKT-RP035	<i>BKT-RS035</i>
RC-1230	BKT-RP036	<i>BKT-RS036</i>
RC-1240	BKT-RP036	<i>BKT-RS036</i>
RC-1250	BKT-RP037	<i>BKT-RS037</i>
RC-1260	BKT-RP038	<i>BKT-RS038</i>
RC-1270	BKT-RP039	<i>BKT-RS039</i>
RC-1280	BKT-RP039	<i>BKT-RS039</i>
RCS		
PA-10	BKT-RP049	<i>BKT-RS049</i>
PA-25	BKT-RP049	<i>BKT-RS049</i>
PA-50	BKT-RP050	<i>BKT-RS050</i>
PA-100	BKT-RP050	<i>BKT-RS050</i>
PA-211	BKT-RP051	<i>BKT-RS051</i>
PA-421	BKT-RP051	<i>BKT-RS051</i>
PA-751	BKT-RP052	<i>BKT-RS052</i>
PAS-18	BKT-RP049	<i>BKT-RS049</i>
PAS-33	BKT-RP050	<i>BKT-RS050</i>
PAS-85	BKT-RP050	<i>BKT-RS050</i>
PAS-111	BKT-RP051	<i>BKT-RS051</i>
PAS-261	BKT-RP051	<i>BKT-RS051</i>
PAS-301	BKT-RP052	<i>BKT-RS052</i>
PAS-401	BKT-RP052	<i>BKT-RS052</i>
SVF/HABONIM		
H15	BKT-RX189	<i>BKT-RS189</i>
H20	BKT-RX190	<i>BKT-RS190</i>
H25	BKT-RX190	<i>BKT-RS190</i>
H30	BKT-RX190	<i>BKT-RS190</i>
H35	BKT-RX191	<i>BKT-RS191</i>
H45	BKT-RX191	<i>BKT-RS191</i>
H60	BKT-RX192	<i>BKT-RS192</i>
H70	BKT-RX192	<i>BKT-RS192</i>
ROTORKR-RANGE		
180	CALL	<i>CALL</i>
400	CALL	<i>CALL</i>
750	CALL	<i>CALL</i>
1000	CALL	<i>CALL</i>
1500	CALL	<i>CALL</i>
2250	CALL	<i>CALL</i>
3000	CALL	<i>CALL</i>
7000	CALL	<i>CALL</i>
TRIAC		
TR20	BKT-RP009	<i>BKT-RS009</i>
TR40	BKT-RP009	<i>BKT-RS009</i>
TR80	BKT-RP009	<i>BKT-RS009</i>
TR130	BKT-RP009	<i>BKT-RS009</i>
TR200	BKT-RP009	<i>BKT-RS009</i>
TR300	BKT-RP010	<i>BKT-RS010</i>
TR500	BKT-RP164	<i>BKT-RS164</i>
TR850	BKT-RP164	<i>BKT-RS164</i>
TR1200	BKT-RP012	<i>BKT-RS012</i>
TR1750	BKT-RP012	<i>BKT-RS012</i>
TRUTORQ		
SIZE2	BKT-RP088	<i>BKT-RS088</i>
SIZE4	BKT-RP088	<i>BKT-RS088</i>
SIZE8	BKT-RP088	<i>BKT-RS088</i>

NAMUR

<u>ACTUATOR</u>	<u>PLATED STEEL</u>	<u>STAINLESS STEEL</u>
REMOTECONTROL		
RC-1210*	BKT-NP120	<i>BKT-NS120</i>
RC-1220*	BKT-NP120	<i>BKT-NS120</i>
RC-1230*	BKT-NP120	<i>BKT-NS120</i>
RC-1240*	BKT-NP120	<i>BKT-NS120</i>
RC-1250	BKT-NP120	<i>BKT-NS120</i>
RC-1260	BKT-NP120	<i>BKT-NS120</i>
RC-1270	BKT-NP130	<i>BKT-NS130</i>
RC-1280	BKT-NP130	<i>BKT-NS130</i>
RCS		
PA-10	N/A	<i>N/A</i>
PA-25	N/A	<i>N/A</i>
PA-50	N/A	<i>N/A</i>
PA-100	N/A	<i>N/A</i>
PA-211	N/A	<i>N/A</i>
PA-421	N/A	<i>N/A</i>
PA-751	N/A	<i>N/A</i>
PAS-18	N/A	<i>N/A</i>
PAS-33	N/A	<i>N/A</i>
PAS-85	N/A	<i>N/A</i>
PAS-111	N/A	<i>N/A</i>
PAS-261	N/A	<i>N/A</i>
PAS-301	N/A	<i>N/A</i>
PAS-401	N/A	<i>N/A</i>
SVF/HABONIM		
H15	N/A	<i>N/A</i>
H20	N/A	<i>N/A</i>
H25	N/A	<i>N/A</i>
H30	N/A	<i>N/A</i>
H35	N/A	<i>N/A</i>
H45	N/A	<i>N/A</i>
H60	N/A	<i>N/A</i>
H70	N/A	<i>N/A</i>
ROTORKR-RANGE		
180	BKT-NP120	<i>BKT-NS120</i>
400	BKT-NP120	<i>BKT-NS120</i>
750	BKT-NP120	<i>BKT-NS120</i>
1000	BKT-NP120	<i>BKT-NS120</i>
1500	BKT-NP120	<i>BKT-NS120</i>
2250	BKT-NP120	<i>BKT-NS120</i>
3000	BKT-NP120	<i>BKT-NS120</i>
7000	BKT-NP120	<i>BKT-NS120</i>
TRIAC		
TR20*	BKT-NP120	<i>BKT-NS120</i>
TR40*	BKT-NP120	<i>BKT-NS120</i>
TR80*	BKT-NP120	<i>BKT-NS120</i>
TR130*	BKT-NP120	<i>BKT-NS120</i>
TR200*	BKT-NP120	<i>BKT-NS120</i>
TR300	BKT-NP120	<i>BKT-NS120</i>
TR500	BKT-NP130	<i>BKT-NS130</i>
TR850	BKT-NP130	<i>BKT-NS130</i>
TR1200	BKT-NP130	<i>BKT-NS130</i>
TR1750	BKT-NP130	<i>BKT-NS130</i>
TRUTORQ		
SIZE2*	BKT-NP120	<i>BKT-NS120</i>
SIZE4*	BKT-NP120	<i>BKT-NS120</i>
SIZE8*	BKT-NP120	<i>BKT-NS120</i>

BRACKET KIT PART NUMBER LIST

S T A N D A R D	ACTUATOR	PLATED STEEL	STAINLESS STEEL	N A M U R	ACTUATOR	PLATED STEEL	STAINLESS STEEL
	SIZE12	BKT-RP088	BKT-RS088		SIZE12	BKT-NP120	BKT-NS120
	SIZE20	BKT-RP089	BKT-RS089		SIZE20	BKT-NP120	BKT-NS120
	SIZE35	BKT-RP090	BKT-RS090		SIZE35	BKT-NP158	BKT-NS158
	SIZE55	BKT-RP091	BKT-RS091		SIZE55	BKT-NP130	BKT-NS130
	SIZE70	BKT-RP091	BKT-RS091		SIZE70	BKT-NP130	BKT-NS130
	SIZE100	BKT-RP091	BKT-RS091		SIZE100	BKT-NP130	BKT-NS130
	SIZE150	BKT-RP091	BKT-RS091		SIZE150	BKT-NP130	BKT-NS130
	SIZE250	CALL	CALL		SIZE250	BKT-NP159	BKT-NS159
	SIZE400	CALL	CALL		SIZE400	BKT-NP159	BKT-NS159
UNITORQ				UNITORQ			
M20	BKT-RP008	BKT-RS008	M20*	BKT-NP120	BKT-NS120		
M30	BKT-RP008	BKT-RS008	M30*	BKT-NP120	BKT-NS120		
M52	BKT-RP008	BKT-RS008	M52*	BKT-NP120	BKT-NS120		
M73	BKT-RP008	BKT-RS008	M73*	BKT-NP120	BKT-NS120		
M103	BKT-RP002	BKT-RS002	M103*	BKT-NP120	BKT-NS120		
M148	BKT-RP002	BKT-RS002	M148*	BKT-NP120	BKT-NS120		
M222	BKT-RP010	BKT-RS010	M222	BKT-NP120	BKT-NS120		
M295	BKT-RP010	BKT-RS010	M295	BKT-NP120	BKT-NS120		
M470	CALL	CALL	M470	BKT-NP166	BKT-NS130		
M586	BKT-RP011	BKT-RS011	M586	BKT-NP130	BKT-NS166		
M1213	BKT-RP012	BKT-RS012	M1213	BKT-NP130	BKT-NS130		
M2366	BKT-RP012	BKT-RS012	M2366	BKT-NP130	BKT-NS130		
M2950	BKT-RP012	BKT-RS012	M2950	BKT-NP130	BKT-NS130		
VALBIA				VALBIA			
A32	CALL	CALL	A32	CALL	CALL		
A52	CALL	CALL	A52	BKT-NP151	BKT-NS151		
A63	CALL	CALL	A63	BKT-NP151	BKT-NS151		
A75	CALL	CALL	A75	BKT-NP151	BKT-NS151		
A85	CALL	CALL	A85	BKT-NP151	BKT-NS151		
A100	CALL	CALL	A100	BKT-NP151	BKT-NS151		
A125	CALL	CALL	A125	BKT-NP151	BKT-NS151		
A160	CALL	CALL	A160	BKT-NP151	BKT-NS151		
A200	CALL	CALL	A200	BKT-NP151	BKT-NS151		
WORCESTER(old)				WORCESTER(new)			
0539	BKT-RP170	BKT-RS170	0539N	CALL	CALL		
1039	BKT-RP016	BKT-RS016	1039N*	BKT-NP120	BKT-NS120		
1539	BKT-RP017	BKT-RS017	1539N*	BKT-NP120	BKT-NS120		
2039	BKT-RP018	BKT-RS018	2039N*	BKT-NP120	BKT-NS120		
2539	BKT-RP019	BKT-RS019	2539N	BKT-NP120	BKT-NS120		
3039	BKT-RP020	BKT-RS020	3039N	BKT-NP151	BKT-NS151		
3339	BKT-RP092	BKT-RS092	3339N	BKT-NP151	BKT-NS151		
3539	BKT-RP021	BKT-RS021	3539N	BKT-NP151	BKT-NS151		
4039	BKT-RP022	BKT-RS022	4039N	BKT-NP161	BKT-NS161		
4239	N/A	N/A	4239N	BKT-NP161	BKT-NS161		
4539	BKT-RP023	BKT-RS023	4539N	BKT-NP161	BKT-NS161		

NAMUR Engineered Resin Bracket Kits

- Fit NAMUR actuators marked with an asterisk (*)
- Kits include dual O-rings to seal actuator/indicator shafts and mounting hardware.

For Sentinel / Survivor: BKT-XP20S
 For Watchman: BKT-XP20W

All bracket kits include mounting hardware (screws, nuts, washers, etc.) compatible with the actuator.

NOTE: New brackets are periodically added to the list. Please contact Moniteur for brackets not shown - Moniteur can design and supply brackets to your specifications.

NAMUR shaft lengths

- Moniteur's standard NAMUR shaft bracket is 1.14" high, and interfaces with Moniteur's shaft type "5".
- Moniteur also offers longer NAMUR shafts (type "E") and brackets to fit the common 1.77" bracket height:

Part number: replace "NP" with "EP"